

Tactical Sling Bag

User manual



Content

1. Product overview	3
2. Usage, maintenance and care	4
Contacts	5

1. Product overview

Tactical sling bags are compact shoulder bags designed to keep everyday essentials and small equipment close at hand. They are suitable for tactical tasks, travel, outdoor activities and everyday use.

This manual applies to all tactical sling bag models, sizes and colours. The capacity, dimensions, weight, material and compartment layout of your model are given on the product label and in the product datasheet. Some features described below may not be available on every model.

Features

- **Durable fabric:** Abrasion-resistant technical fabric for demanding use.
- **Multiple compartments:** Zippered compartments for safe storage and quick access to essentials.
- **MOLLE attachment system:** Lets you attach compatible pouches and accessories to the bag.
- **Patch panel:** Lets you attach patches to the bag.
- **Adjustable strap:** Lets you adjust the bag for a comfortable fit across the body.

2. Usage, maintenance and care

Usage

- **Before first use:** Remove the packaging and check that all zips and the strap work properly.
- **Wearing:** Wear the bag across the body and adjust the strap so the bag sits snugly.
- **Packing:** Place heavy items in the main compartment, close to your body; keep small items in the outer compartments.
- **Attaching accessories:** Weave the pouch strap alternately through the MOLLE slots and the pouch webbing, then secure the strap end.
- **Grab handle:** Use the handle to carry the bag by hand or to hang it up.
- **Load:** Do not overload the bag or force zips closed. Keep sharp objects away from the fabric.

Operating and storage conditions

Parameter	Value
Operating temperature	–20 to +60 °C
Storage temperature	–30 to +60 °C
Storage conditions	Store dry in a well-ventilated place
Sunlight	Avoid prolonged exposure to direct sunlight
Heat sources	Keep away from open flame and heat sources

Care instructions

Care step	Instruction
Cleaning	Spot clean with a damp cloth or soft brush
Washing	Hand wash only, max 30 °C
Detergent	Use a mild detergent
Bleaching	Do not bleach
Drying	Air dry; do not tumble dry
Ironing	Do not iron

- **Storage:** Empty the bag before cleaning. Never store it wet or damp, as this can cause odour and mould.
- **Inspection:** Check seams, the strap and zips regularly; keep zips free of sand and dirt. Do not use the bag near open flame: synthetic fabric can melt.

Contacts

WhatsApp: +420 776 345 933

Email: support@partizanarsenal.cz

Telegram: https://t.me/PartizanSupport_bot