

Portable Water Filter

User manual



Content

1. Product overview	3
2. Usage, maintenance and care	4
Contacts	5

1. Product overview

Portable water filters are compact devices for filtering water from natural sources during hiking, camping, travel and outdoor activities. Depending on the model, they can be used as a drinking straw or connected to a bottle or water bag, and may include survival features such as a whistle, compass or carabiner.

This manual applies to all portable water filter models and colours. The filtration performance, flow rate, filter life, dimensions and weight of your model are given on the product label and in the product datasheet. Some features described below may not be available on every model.

Features

- **Compact design:** Lightweight filter for outdoor carry.
- **Long filter life:** Filters a large volume of water before replacement.
- **Durable housing:** Impact-resistant plastic housing.
- **Survival features:** Whistle, compass and carabiner, depending on the model.

2. Usage, maintenance and care

Usage

- **Before first use:** Remove the caps and flush the filter with water, discarding the first portion.
- **Water source:** Use the clearest water available. Let cloudy water settle or pre-filter it through a cloth.
- **Drinking:** Drink through the mouthpiece or connect the filter to a bottle or water bag. Keep the outlet away from unfiltered water.
- **Limitations:** Unless stated for your model, the filter does not remove viruses, chemicals, salt or heavy metals. Do not use it with seawater.
- **Filter life:** Replace the filter after its rated volume or when the flow drops and cannot be restored.

Operating and storage conditions

Parameter	Value
Operating temperature	0 to +50 °C
Storage temperature	–30 to +60 °C (dry filter only)
Storage conditions	Store dry; protect from freezing after use
Sunlight	Avoid prolonged exposure to direct sunlight
Heat sources	Keep away from open flame and heat sources

Care instructions

Care step	Instruction
Flushing	Flush with clean water after each use
Housing cleaning	Wipe with a damp cloth
Hot water	Do not use boiling water
Chemicals	No bleach, solvents or detergents inside
Drying	Shake out water; air dry with caps off
Freezing	Do not let a wet filter freeze

- **Storage:** Dry the filter completely before long-term storage, then fit the caps to keep it clean.
- **Inspection:** Check the housing and caps for cracks before each use. Do not use a filter that has frozen when wet or is cracked, as it may no longer filter water safely.

Contacts

WhatsApp: +420 776 345 933

Email: support@partizanarsenal.cz

Telegram: https://t.me/PartizanSupport_bot