

Shower Tent

User manual



Content

1. Product overview	3
2. Usage, maintenance and care	4
3. Setup and folding	5
Contacts	6

1. Product overview

Shower tents are lightweight portable shelters that provide privacy for showering, changing or relaxing outdoors. They are suitable for camping, fishing, hiking, picnics and other outdoor activities.

This manual applies to all shower tent models, sizes and colours. The capacity, dimensions, weight, materials and waterproof rating of your model are given on the product label and in the product datasheet. Some features described below may not be available on every model.

Features

- **Freestanding design:** Opens and sets up quickly.
- **Waterproof fabric:** Protects against light rain.
- **UV-resistant fabric:** Resists exposure to sunlight.
- **Breathable construction:** Provides comfortable ventilation inside the tent.

2. Usage, maintenance and care

Usage

- **Before first use:** Check the fabric, poles and zips for damage. Practise setting up and folding the tent before your trip.
- **Pitching:** Choose a flat, firm surface free of sharp objects. In windy conditions, secure the tent with pegs and guy lines, if supplied.
- **Showering:** Do not hang a water bag or other loads from the tent frame unless your model is designed for it.
- **Weather:** The tent is designed for light rain only. Do not use it in strong wind, storms or snow.
- **Folding:** Close all zips and fold the tent as shown in section 3. Do not force the frame.

Operating and storage conditions

Parameter	Value
Operating temperature	0 to +50 °C
Storage temperature	–30 to +60 °C
Storage conditions	Store fully dried in a well-ventilated place
Sunlight	Avoid prolonged exposure to direct sunlight
Heat sources	Keep away from open flame and heat sources

Care instructions

Care step	Instruction
Cleaning	Wipe with a damp cloth or soft brush
Washing	Do not machine wash
Detergent	Use mild soap only
Bleaching	Do not bleach or use solvents
Drying	Dry fully before packing; do not tumble dry
Ironing	Do not iron

- **Storage:** Shake out sand and dirt and dry the tent completely before packing. Never store it damp, as this can cause odour and mould.
- **Inspection:** Check the fabric, seams, poles and zips regularly. Do not use the tent near open flame or heaters: synthetic fabric can melt.


3. Setup and folding

The steps below apply to pop-up shower tents. Your model may differ slightly.


Setup



1. Remove the tent from the carrying bag and unfasten the elastic cord.




2. Hold the tent away from your face and other people, and release it into an open area. The tent opens automatically.




3. Secure the tent with pegs, if supplied.


Folding



1. Step on the tent bottom with one foot, hold the top with both hands and fold the tent inwards.




2. Fold the roof down to the bottom and hold it in place with your foot.




3. Pull the two arched sides inwards together with both hands.




4. Hold the overlapped arches with one hand and the folded roof with the other.




5. Keeping your foot on the bottom, push the folded roof gradually into the interior.



6. Press one arch down and push the other inwards on top of it until they overlap.



7. Press the folded tent into a flat, round shape.



8. Fasten the folded tent with the elastic cord.



9. Put the tent and all accessories into the carrying bag.

Contacts

WhatsApp: +420 776 345 933

Email: support@partizanarsenal.cz

Telegram: https://t.me/PartizanSupport_bot